




SDT&DT Meter Quick Install Instruction






Meter Working Principle & Connection




The Meter for SDT and DT is used for limiting transfer power from inverter to grid. It is connected between inverter and grid. Arrows direction means it is from inverter to grid. There are 3 firing lines and 1 null line. The communication line connects to port 7 &8 on Meter which as Picture 1 showed below.





Communication line connection



Meter Working Principle & Connection








Picture 3

Power Limit Configuration




After connect Meter , when SDT & DT screen displays level 1 menu , short press 'Enter' button to find below interface then , press 'up' and 'down' to find the interface which as Picture 6 showed.










Power Limit Configuration




When you see Picture 6 showed interface , short press 'Enter' button to find 'Limit OFF' interface (the default setting is OFF) , long press 'Enter' button to change 'Limit OFF' to 'Limit ON' which as Picture 7 & 8 showed below.









Power Limit Configuration



When you see Picture 8 showed interface , press 'Down' button to enter power limit settings . Every number you set successfully then press 'Enter' button to go to the next number set . When the percentage is set successfully , long press 'Enter' to save.







Q1 : What length for SDT&DT Meter's communication line?

A1 : Can use RS485 line , the length should be within 100m.

Q2 : What is the max current for SDT&DT Meter?

A2:80A



Thanks GOODLE your solar engine