# Jackery
Power Outdoors

Welcome Guide

Model: Jackery PowerBar

Congratulations on purchasing Jackery premium portable AC battery pack, we recommend that you read through this manual carefully before using it for the first time.

Package Content

1 x AC Adapter
1 x Portable AC Battery Pack
1 x USB C Cable
1 x User Manual
1 x Thank You Card

Product Diagram

① Power Button
② LCD Indicator
③ USB Output
④ USB C Output
⑤ Quick Charge 3.0 Output
⑥ AC Output

Product Specifications

Capacity	20800mAh @3.6V (76.96Wh)	
Input	USB C 5V 3A	
USB-C Output	DC 5V/3A	
USB Output	Quick Charge 3.0	
USB Output	5V 2.4A	
AC Output	110V 85W (100Max)	
Size	160X65X65mm	
Weight	1.6 Lbs	

Using Your Jackery PowerBar

Charge your device (USB output charge your device automatically once you connect with a cable)

(Do not exceed 100W)

Lights   Game Player   Laptop

Note: The USB output will charge your device automatically once connect with a cable, while the AC output you will have to press and hold the power button for 2 seconds and off it by doing same after using.

You will hear the cooling fan is working once you active the AC output, please turn it off when it is not in use, or it will drain your battery fast

Recharge your Jackery PowerBar (Plug into the wall adapter)

Note: Recharging time depends on your adapter, the PowerBar recieves 15 W max power, ie. if you are using a 5V 3A adapter it will take about 7 hours to fully charge.

Attention

To preserve lifespan recharge every 3- month, it is normal for the battery pack to become slightly warm during charging / discharging

Not waterproof ,do not expose to liquids

Do not disassemble

Avoid dropping

Avoid extreme temperature

Not Charging?

If after connecting, your battery pack is not charging your device:

1. Charge the battery pack to full capacity

2. Try a different cable (use original OEM cable if possible)

3. Try a different connection sequence   (connect the charging cable to the battery pack first, then connect with your device)

4. Contact our customer support

Jackery Warranty

Received Order

Satisfied → Yes → Leave your feedback or review on Amazon → Share with your friends

No

Contact Hello@jackery.com with an RMA Request

Jackery issues RMA → Covered by 30 days worry free guarantee? → Yes → Prepaid shipping label is provided by Jackery

No

Customer is responsible for return shipping

Customer receive refund or replacement

Customer Service

24 - month limited warranty

Lifetime technical support

Hello@jackery.com

4086188916 | Mon-Fri 9:00-5:00 PST (US)

@jackery.inc   @jackeryinc

For more information, please visit us at www.jackery.com